




## THE WATER WORKS FRESH WATER AUXILIARY TANK

### SPECIFICATIONS

Height	60 in	152 cm
Diameter	23 in	58 cm
Tank Capacity	100 gal	378 ltr
Weight Empty	32 lb	14.52 kg
Weight Full	866.5 lb	392.97 kg



### CAUTION

DISCONNECT FWD2-1000 FROM POWER SOURCE PRIOR TO PERFORMING ANY MAINTENANCE OR SERVICE WORK

#### **POLYJOHN USA**

PolyJohn Enterprises Corp  
2500 Gaspar Ave.  
Whiting, IN 46394  
Phone: 800-292-1305  
Fax: 219-659-0625  
www.polyjohn.com  
info@polyjohn.com

#### **POLYJOHN WORLDWIDE**

PolyJohn (UK) Ltd.  
Equinox 1 Audby Lane  
Wetherby, England LS22 7RD  
Phone: 44 (0) 1937-583333  
Fax: 44 (0) 1937-583322  
www.polyjohn.co.uk  
sales@polyjohn.co.uk

#### **POLYJOHN CANADA**

PolyJohn Canada  
P.O. Box 2300  
199 Forest Plain Rd.  
Orillia, Ontario LV3 6S2  
Phone: 800-465-9590  
Fax: 705-325-8250  
www.polyjohncanada.ca  
info@polyjohncanada.ca

### Parts Included

- 4 - PC-000351 Hose Clamps #10
- 2 - CH075-023 Reinforced Hose 3/4" x 23"
- 4 - PC-000323 Hose Barb Fitting 1/2" MPT x 3/4"
- 1 - PC-000347 FPT Tee Fitting 1/2"

### General Product Overview

This 100 gallon holding tank works in conjunction with the FWD2-1000 to allow a capacity of 200 gallons of fresh water. When hooked up to an existing FWD2-1000 it acts as one tank. All the necessary plumbing is included.

### Set-up Operation Information

- Step 1.** Make sure the fresh water is drained from the FWD2-1000. If existing plumbing is attached to the bottom of FWD2-1000 disconnect or remove drain plug. Remove the drain plug from the bottom of the FWD1-0500 tank.
- Step 2.** Thread one of the 1/2" MPT Hose Barb Fittings onto the bottom of the existing FWD2-1000 tank. (Teflon plumbing tape is recommended to thread the fittings.) Slip one of the hose clamps over one end of the 3/4" Reinforced Hose and attach to the 1/2" MPT Hose Barb Fitting that is connected to the bottom of the FWD2-1000 and tighten hose clamp. Follow this procedure for the FWD1-0500.
- Step 3.** Slip the other hose clamps over both hoses that are already connected to each of the tanks. Insert the 1/2" FPT Tee Fitting into each of the hoses and tighten hose clamps at each end of the tee.
- Step 4.** At this point if any drain plumbing existed, it can now be attached to the 1/2" FPT Tee Fitting. If no plumbing existed, then the tether needs to be cut off of the 1/2" Drain Plug and inserted along with the 1/2" O-Ring into the open end of the 1/2" FPT Tee Fitting. Please refer to the Operations Manual for filling and service procedures.

### MISSION STATEMENT

"PolyJohn is a family owned, state of the art, plastics manufacturing company dedicated to providing its employees with a work environment committed to excellence, and its customers with innovative products, services and technology that meet or exceed their requirements."

### **THANK YOU FOR PURCHASING POLYJOHN PRODUCTS!**

Look for us on the Web @ [www.PolyJohn.com](http://www.PolyJohn.com)